KINCROME C L⊙IX•⊙L

Maintenance Kit Contents:

- 1 Quick Release Gear 2 Backing Plate
- 3 Selector Mechanism
- 4 Pawl
- 5 Selector Mechanism
- 6 Retaining Pin
 7 2x Screws
 - 8 Retaining Spring
- 9 Selector Mechanism Spring
- 10 Direction Switch



^{*}Maintenance Kit contains grease & TORX® key

KINCROME C LOK-ON

LOK ON Ratchet Maintenance Kit

Instructions

 Use the hex key to remove the screws and disassemble the ratchet

To reassemble

- Insert direction switch.
 Insert larger retaining spring into the slot at base of the ratchet.
- Insert the larger retaining pin into the spring. The extruded end will fit inside the spring.
- 4. Insert the smaller selector mechanism spring into the selector.

 5. Insert smaller retaining.
- Insert smaller retaining pin into the spring of the selector mechanism. The extruded end will fit inside the spring.
- Insert the selector mechanism into the ratchet head.
- Selector and direction switch will connect

Clean the inside of the ratchet once removed

together when inserted correctly.

- Insert the pawl on top of the selector mechanism.
- Apply grease to quick release gear and place
- into the ratchet head.

 10. Screw the backing plate
- back into place with the two provided screws.
- Test the ratchet gear and switch both move freely
- Test the quick release button/function



each way.

SCAN FOR LOCOCOLO FEATURES OR VISIT WEBSITE